BDS System Configuration Chart

Power Source (Input Cables)

BDSNPADW

NP-1 Battery

BDSINANPAG

Anton Bauer Battery w/ Pag 2 connection

BDSINBAUER

Anton Bauer Gold Mount w/ Power Tap

BDSIN

4-pin XLR Battery or Power Supply

BDSINBP

BP-90 Battery

BDSINVL

IDX V-Lock Adapter



BDSUSB

for USB powered devices

BDSCLSR

Lectrosonics SR Receivers & SM Batt Elim

BDSCL33(Y)

(center pin positive)

Lectrosonics 185, 187, 190, 195, 201, 211, 411 Receivers and UM Batt Elim

Audio Technica 100 and 1800 Series Receivers

Marantz PMD670

Remote Audio SPEAKEASY

Samson Micro Series Receivers

Shure UP4, FP-32A & FP-33

SONOSAX SX-PR

Tascam HD-P2 & DR-680

Equipment to Power (Output Cables)

BDSCC104

Cooper CS-104

Edirol R4 Pro

Fostex PD-4, PD-6 & PD-606

HHB Porta-DAT & Porta-Drive

SONOSAX SX-ST

Tascam HS-P82

Zaxcom Deva 4, 5, 5.8, 16 & Fusion recorders

BDSCSQN

PSC M4 mkII, M3, AlphaMix, Promix 6

Sony WRR 862 & 861

Sound Devices 302, 442 & 552 7-Series Recorders, newer MixPre, MixPre-D

SQN 4S Series IV & IVe, 3M Series 4000, SQN-2S, 4S mini & 5S

Wendt X3 & X5

BDSFR2

Fostex FR-2

BDSCM4

(center pin negative)

Edirol R4, R44

PSC M4

Rolls MX442, MX422 & MX410

Shure FP-31 & FP-32 (not for use with FP32A or FP33)

> Wendt X2 & X4

BDSCSD

Sound Devices HX-3, MP-2, MM1, MixPre version 1 and 442 Version 1 Mixers

BDSCZSTA100

Zaxcom STA100, IFB100

BDSCZENG

Zaxcom RX900M, RX900S, & 1st Generation Stereoline ENG Systems

*Please call if your device is not listed. Custom cables also avaible.

